



**1998-2002 Camaro Bolt on Front Dzus Rails
Part # 704074 / 704071**

To install front dzus rails, locate center end of left rail at the center of the front bumper cover. Then adjust rail to the proper height for hood thickness. With a sharp pick mark the center of the slots and drill holes. Insert bolts and tighten to a light snug. Verify final height (slide up or down if necessary) and tighten. Drill the holes for the rest of the mounting locations and secure into place. Repeat above processes for the right side rail. Grinding may be required on some installations to provide clearance for the nylock nuts on the under side of the bumper cover structure.

