



**98-02 Camaro Fender Dzus Rail Installation
Part # 704070**

- 1. To install the fender dzus rails start by mounting the lower adjuster rail first. (Refer to Fig – 1 for location of the first hole)**
- 2. Figure 1 – From the front edge of the fender (above the headlight) to the location of the
Centerline of the first hole for the adjuster rail is 4 inches.**
- 3. Mark and drill hole, insert screw and tighten nut. Repeat process from front to back on remaining holes. Next install upper dzus rail with nylock nuts to the backside.**
- 4. Lightly snug all screws so the top rail can still slide up and down to adjust for hood thickness. Start to adjust the height of the upper dzus rail at the 3rd slot from the front. This is because the lower rail has a hole not a slot, which will locate the upper rail in the correct location front to back so the other screws do not bind. Then continue to adjust the rail height at the 4th and 5th slot and so on to the back. Next adjust the height at the 2nd slot and finish at the 1st slot.**

Installation Pictures Below

Figure 1



Figure 2

