



200 SPRUCE AVE...MADISON LAKE, MN 56063
PHONE: (507) 243-4104...FAX: (507) 243-4097

1982-1992 Camaro 2" Drop Spindle Installation Instructions
Part # 300106/300110

General Installation Guide:

Prior to installing your spindles, make sure you have the correct tools to remove the factory springs. The springs are under compression, and could cause damage to you and/or your vehicle if not removed properly.

General Installation Information

1. Remove the OEM spindles,brakes, and shocks/springs.
2. When using an 82-92 Camaro Strut, use the supplied aluminum strut spacers. If on either side of the mounting tang on the spindle.
3. The strut pinch flange may need slight grinding on one side to clear the weld.
4. Torque the spindle nut to 189-254 in/lb.
5. Torque the strut to spindle flange belts to 141-199 lb/ft.
6. Re-Install brake components, and immediately re-align front suspension.